

SKODA

Component Cover Comparison



Contents

Engine	3
Gearbox	3
Fuel system	3
Electric and Hybrid drive	4
Final drive/transmission shafts	4
Steering	4
Brakes	5
Electrical system	5
Convenience electronics	5
Air conditioning system	6
Cooling system	6
Safety system	6
Exhaust system	7
Factory-fitted LPG	7

T&Cs

This is only a list of components. You'll need to refer to the policy documents for the full list of exclusions, terms and conditions.

Insured Parts	Extended Warranty Essentials	Extended Warranty Standard	Extended Warranty Plus
Engine			
All Internal parts	●	●	●
Crankcase	●	●	●
Cylinder head	●	●	●
Cylinder head gasket	●	●	●
Flywheel	●	●	●
Timing chain / Timing belt	●	●	●
Coolant pump	●	●	●
Timing Chain (Gears or Belt)	●	●	●
Oil cooler	●	●	●
Oil pump	●	●	●
Timing chain cover	-	●	●
Seals and Gaskets	-	●	●
Rocker cover	-	●	●
Crankshaft oil seal housing	-	●	●
Oil sump	-	-	●
Damper pulley	-	-	●
Inlet manifold	-	-	●
Gearbox			
All internal parts	●	●	●
Gearbox housing	●	●	●
Torque converter	●	●	●
Mechatronics	●	●	●
Control unit	●	●	●
Multi plate clutch (automatic gearbox)	●	●	●
Lever module	●	●	●
Seals and Gaskets	-	●	●
Gearbox mounts	-	-	●
Clutch release bearing	-	-	●
Gearbox oil cooler	-	-	●
Gearbox wiring	-	-	●
Fuel system			
Turbocharger	●	●	●
Intercooler	●	●	●
Fuel pump	●	●	●
Fuel injection ECU	●	●	●
Injection pump	●	●	●
Fuel injector	●	●	●
Seals and Gaskets	●	●	●
Oxygen sensor	●	●	●

Insured Parts	Extended Warranty Essentials	Extended Warranty Standard	Extended Warranty Plus
Electric and Hybrid drive			
Traction motor (EV / Hybrid)	•	•	•
Engine control unit (EV / Hybrid)	•	•	•
Traction motor temperature sensor (EV / Hybrid)	•	•	•
Traction motor control unit (EV / Hybrid)	•	•	•
Battery monitoring control unit (EV / Hybrid)	•	•	•
Battery regulator control unit (EV / Hybrid)	•	•	•
Battery voltage converter (EV / Hybrid)	•	•	•
Fan motor for high voltage battery (EV / Hybrid)	•	•	•
Battery charger for high voltage battery (EV / Hybrid)	•	•	•
High voltage charging socket	-	-	•
High voltage charging cable	-	-	•
High voltage battery heat exchanger	-	-	•
Impulse rotor (EV / Hybrid)	-	-	•
High voltage battery wiring harness (EV / Hybrid)	-	-	•
High voltage socket lock actuator (EV / Hybrid)	-	-	•
High voltage charge socket (EV / Hybrid)	-	-	•
Final drive/transmission shafts			
Propshafts	•	•	•
Drive shaft	•	•	•
Constant velocity joint	•	•	•
Propshaft shaft bearing housing	•	•	•
Propshaft shaft flexible coupling	•	•	•
Electronic differential lock	•	•	•
Engine speed sensor	•	•	•
Hydraulic unit	•	•	•
Shaft gaiters	•	•	•
Seal and Gaskets	-	•	•
Steering			
Steering rack	-	•	•
Control unit	-	•	•
Electronic power steering motor	-	•	•
Hydraulic pump	-	•	•
Steering rack bar	-	-	•
Steering column	-	-	•
Steering lock	-	-	•
Steering column lock	-	-	•
Steering wheel heater	-	-	•
Steering wiring loom	-	-	•

Insured Parts	Extended Warranty Essentials	Extended Warranty Standard	Extended Warranty Plus
Brakes			
Brake master cylinder	-	•	•
Parking brake control unit	-	•	•
Anti-lock brake system	-	•	•
Vacuum pump	-	•	•
Emergency brake system	-	•	•
Pedal box	-	•	•
Brake caliper	-	•	•
Brake fluid level sensor	-	•	•
Parking brake electric motor	-	•	•
Brake caliper mounting	-	•	•
Seals and Gaskets	-	•	•
Electrical system			
Starter motor	•	•	•
Starter drive	•	•	•
Alternator-starter combined unit (start/stop)	•	•	•
Alternator	•	•	•
Starter solenoid	•	•	•
Alternator voltage regulator	•	•	•
Alternator pulley	-	•	•
Alternator mounting	-	•	•
Alternator belt tensioner	-	•	•
Supercapacitor	-	•	•
Convenience electronics			
Instrument cluster	-	•	•
Warning switch	-	•	•
Indicator control unit	-	•	•
Light switch	-	•	•
Windscreen wiper motor	-	•	•
Multi-plexing ECU	-	•	•
Door locks	-	•	•
Blower motor	-	•	•
Multimedia control unit	-	•	•
Window heating element	-	-	•
Sat nav screen	-	-	•
Parking sensor	-	-	•
Cruise control system	-	-	•
Lane change assistant	-	-	•

Insured Parts	Extended Warranty Essentials	Extended Warranty Standard	Extended Warranty Plus
Air conditioning system			
Compressor	-	•	•
Condenser	-	•	•
Fan	-	•	•
Evaporator	-	•	•
Compressor clutch	-	•	•
Regulator pressure valve	-	-	•
Schrader valve	-	-	•
Air quality sensor	-	-	•
Air conditioning controls	-	-	•
Temperature Sensor	-	-	•
Cooling system			
Radiator	-	•	•
Thermostat	-	•	•
Heat exchanger	-	•	•
Fan coupling	-	•	•
Exhaust gas cooler	-	•	•
Cooler for automatic gearbox	-	-	•
Visco/thermo fan	-	-	•
Viscous coupling pulley	-	-	•
Coolant level sensor	-	-	•
Radiator fan wiring harness	-	-	•
Safety system			
Control unit for airbag and belt tensioner	-	•	•
Setting ring	-	•	•
Seat occupied sensor	-	•	•
Sensor mat	-	•	•
Control unit and sensors for electronic stability control (ESC)	-	•	•
Crash acceleration sensor	-	•	•
Longitudinal acceleration sensor	-	•	•
Transverse acceleration sensor	-	•	•
Airbag	-	-	•
Airbag wiring loom	-	-	•
Seat belt pre-tensioner	-	-	•
Tyre pressure monitor sensor – TPMS	-	-	•
Anti-collision radar	-	-	•
Anti-collision radar control unit	-	-	•
Anti-collision camera	-	-	•
Seat belt	-	-	•

Insured Parts	Extended Warranty Essentials	Extended Warranty Standard	Extended Warranty Plus
Exhaust system			
Lambda probe	-	•	•
NOx sensor	-	•	•
Control unit for NOx sensor	-	•	•
Exhaust gas temperature sensor	-	•	•
Delivery module for urea solution AdBlue®	-	•	•
Heater for reducing agent tank	-	-	•
Exhaust regulator flap	-	-	•
Diesel particulate filter control unit	-	-	•
Diesel particulate filter differential sensor	-	-	•
Reducing agent wiring loom	-	-	•
Diesel particulate filter wiring harness	-	-	•
Reducing agent tank breather	-	-	•
Factory-fitted LPG			
LPG/CNG regulator	-	-	•
LPG/CNG fuel changeover switch	-	-	•
LPG/CNG injector rail	-	-	•
LPG/CNG injector	-	-	•
LPG/CNG solenoid valve	-	-	•
LPG/CNG electronic module	-	-	•
LPG/CNG flow limiter	-	-	•
LPG/CNG overfill limiter	-	-	•
LPG/CNG pressure gauge sender	-	-	•
LPG/CNG anti return valve	-	-	•
LPG/CNG safety valve	-	-	•
LPG/CNG distributor sensor	-	-	•
LPG/CNG pressure gauge	-	-	•
LPG/CNG shut off valve	-	-	•
LPG/CNG filling connection with stop valve	-	-	•